

### LEAK DETECTOR LIFTING GUIDE

## **UNPACK**

Remove the following items from top of TITAN VERSA leak detector:


- Documentation Package
- Tools and Spares Case
- Lifting Kit Bag and Replacement Hardware



LIFT

#### **WARNING:**

The TITAN VERSA should only be removed from shipping container using the following conditions:



- Use of either 1) a lifting crane or 2) a two-person lift to remove unit from packaging
- 1. Remove foam panels from sides of leak detector.
- 2. Remove protective plastic from leak detector.
- 3. Use the yellow lifting strap to remove leak detector.

#### **WARNING:**

Do not allow leak detector to tip more than 20 degrees.

# **REPLACE**

1. Detach yellow lifting strap and D-rings from lifting bolts.



2. Remove lifting bolts and store with strap in lifting kit bag.



3. Locate two M8 screws and 5mm hex adapter from lifting kit bag and install screws where lifting bolts were originally located.



